


CITTÀ

Point Floor Lamp

EBL0025TLU & EBL0025FLU



Step 1

Carefully screw the stem onto the base.


Step 2

Place the glass lampshade over the lamp stem, make the collar of the lampshade is sitting on the platform of the lamp stem bracket.

CITTÀ

Point Floor Lamp

All other codes



Step 1

Carefully screw the stem onto the base.

Step 2

Unscrew and remove the top collar from the lamp stem.

Step 3

Place the glass lampshade over the lamp stem, make the collar of the lampshade is sitting on the platform of the lamp stem bracket.

Step 4

Screw back on the top collar and tighten it to fix the glass lampshade, do not overtighten.

Point Floor Lamp

| Product Name | SKU | Input | CCT. | Lamp Shade Colour | Lamp Body Colour | Power |
|------------------|------------|--------|-------|-------------------|------------------|-----------|
| Point Floor Lamp | EBL0007FLU | 120VAC | 2700K | Clear | White | Max. 2.5W |
| Point Floor Lamp | EBL0008FLU | 120VAC | 2700K | Smoke Grey | Black | Max. 2.5W |
| Point Floor Lamp | EBL0025FLU | 120VAC | 2700K | Amber | Black | Max. 2.5W |
| Point Table Lamp | EBL0007TLU | 120VAC | 2700K | Clear | White | Max. 2.5W |
| Point Table Lamp | EBL0008TLU | 120VAC | 2700K | Smoke Grey | Black | Max. 2.5W |
| Point Table Lamp | EBL0025TLU | 120VAC | 2700K | Amber | Black | Max. 2.5W |

TA:25

MADE IN CHINA



Read the following instructions before handling the product:

1. Switch off the power of the mains supply and respectively of the connection lead before handling the product at installation, maintenance and cleaning etc.
2. Only to be operated with the specified driver.
3. Only for indoor use in dry conditions and not in dirt endangered rooms or in areas with high air humidity.
4. The product must not be exposed to strong mechanical loads.
5. Do not cover the product, as free air circulation must be provided.
6. The product must not be modified and use only parts which are supplied with the product or are described as accessories.
7. Operate the product only if it is working correctly.
8. Switch off the product with a malfunction immediately and operate it again only after examination by an electrical specialist in case of the following: Visible damage, it stops working, smoke, steam or crackling sounds, overheating is observed.
9. Repairs or work on mains voltage may only be carried out by a qualified electrician.
10. If the above instructions are not followed, short circuits and electrical shocks may occur.
11. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or similar qualified person in order to avoid a hazard.
12. The light source contained in this light shall only be replaced by the manufacturer or his service agent or similar qualified person.
13. Switch off the power of the mains supply as well as the connection lead before installing the product.
14. The LED bulbs have a warranty of 50,000 hours or 3 years, replacement in line switch and wall plugs are available but need to be fitted by a qualified electrician.
15. Please note: glass blowing is an organic hand made process, so there may be some imperfections like small air bubbles visible in the finished product, we do not classify this as a fault.