

# CITTÀ

## cleaning guidelines

---

### point lighting range

Proper care and cleaning of our Point lighting range helps to preserve appearance. Over time, general dust and condensation (caused by seasonal changes and humidity) may cause a light film to settle on the inner and outer surfaces of your glass shade.

The best way to care for and clean your glass shade is by following the method outlined. We do not recommend using solvents to clean the shade.



# cleaning guidelines

---

## Cleaning tools

- Clean microfibre cloth
- Spray bottle with water
- Long-handled brush with soft tip (or sponge brush)
- Hairdryer



---

## Cleaning method



1. Dampen the microfibre cloth with the water spray bottle. Try not to over-saturate as this may cause streaking. Use gloves to avoid fingerprints when handling your glass shade.



2. Carefully place the damp cloth inside the shade.



3. Insert the long-handled brush to carefully move the cloth around the inner surface of the shade.



4. Remove the cloth from the shade.



5. Clean the outer surface of the shade with the damp cloth.



6. Dry the inner and outer surfaces of the shade with the hairdryer. We recommend using cold air at a high speed.

7. If you notice residual marks on shade, repeat the process.

**CITTÀ**